



GRIPPER SUB ASSEMBLY




PART NUMBER	QTY.
MG996R-1	1
M5 20mm SHCS	2
HEX NUT M5	2
WASHER M3	8
M3 L18	4
98952A106_ALUM FEM THRD HD HEX STANDOFF	4
90224A173_M2 TOOL STEEL EJECTOR PIN	1
6056N140_SET SCREW SHAFT COLLAR	1
PART 200W	1
Adaptor Connector Plate	1
Slider Left1	1
LM6UU	2
94459A140_BRASS HEAT-SET INSERT FOR PLASTIC	4
Slider RIGHT	1
94669A101_ALUM UNTHRD SPACER	4
M3 L12	2
M3 L20	2
Rotating Link	1
Rotating Link Left	1
PART 100W	1
M3 L8	4
Aluminum Horn	1
HEX NUT M3	2


GRIPPER SUB ASSEMBLY STEP 1




GRIPPER SUB ASSEMBLY
STEP 1



ISOMETRIC VIEWS
ASSEMBLED





GRIPPER SUB ASSEMBLY
STEP 2



GRIPPER SUB ASSEMBLY
STEP 2


ISOMETRIC VIEWS
ASSEMBLED




GRIPPER SUB ASSEMBLY
STEP 3

SLIDE PIN FROM THIS SIDE
THRU BOTH LINEAR BUSHINGS
AND FASTEN COLLAR WITH SET SCREW
ON THE OTHER END

90224A173
M2 TOOL STEEL EJECTOR PIN




6056N140
SET SCREW SHAFT COLLAR




ISOMETRIC VIEW
ASSEMBLED


GRIPPER SUB ASSEMBLY
STEP 4




GRIPPER SUB ASSEMBLY
STEP 4



ISOMETRIC VIEW
ASSEMBLED



GRIPPER SUB ASSEMBLY
STEP 5



GRIPPER SUB ASSEMBLY
STEP 5

ISOMETRIC VIEW
ASSEMBLED

